

DreamTime Trouble shooting Guide

Important Note: For any unusual problem, system reset your radio as explained on page 28 of the Instruction book.

Symptoms	Cause/cure (✖)
<p>1. Radio cuts out.</p> <p>http://www.ukdigitalradio.com/advice/toptips/</p>	<ul style="list-style-type: none"> • Make sure the aerial is uncoiled. Reposition the radio/aerial to get maximum signal strength. • Check the digital radio (DAB) coverage in your area using the link – www.ukdigitalradio.com/coverage/search/default.asp <p>The type of building and surroundings can seriously affect the DAB reception. Sizeable concrete and metal work in the building (e.g. Block of flats, shopping centre, near or under a bridge, thermal insulation with metal foil in the loft) can considerably reduce the signal strength.</p> <p>Under these circumstances, an outdoor aerial is required for the optimum reception.</p>
<p>2. Cannot receive BBC Sports Extra, display shows “Not Available”.</p>	<ul style="list-style-type: none"> • This radio station is not transmitting all the time. Transmitting details can be found using following links. http://www.bbc.co.uk/5livesportsextra/commentaries/ <p>See Secondary services – DAB on page 7.</p>
<p>3. Not all the stations showing in the list.</p>	<ul style="list-style-type: none"> • Fully extend the aerial and perform “Finding new stations – DAB” as suggested on page 9.
<p>4. Sound Quality???</p>	<p>Check the DRC value, should be set to ‘0’ unless listening in a noisy environment.</p>
<p>5. Not keeping correct time.</p>	<p>Regularly switch on in DAB mode or briefly disconnect the power.</p>
<p>6. How to set Alarm 1?</p>	<ul style="list-style-type: none"> • Switched on the radio. • Quickly press and release ‘Alarm’ button. (‘ALARM 1’ will display on the screen.) • Quickly press and release ‘Select, button. Display may show ‘ON’ or ‘OFF’. If display shows ‘OFF’ then quickly press and release ‘TUNING▲’ button. • When display shows ‘ON’, quickly press and release ‘Select, button. • Now select the hour for alarm time by repeatedly pressing ‘TUNING▲’. When correct hour is displayed press select button quickly. • Now select the minute for alarm time by repeatedly pressing ‘TUNING▲’. When correct minute is displayed press the ‘SELECT’ button quickly. • Now select the desired day option by repeatedly pressing ‘TUNING▲’ then quickly press the ‘SELECT’ button. • Choose the desired option ‘BUZZ’ or ‘RADIO’ using ‘TUNING▲’ then quickly press the ‘SELECT’ button. Display will show ‘SAVED’ – this ends the procedure for setting alarm1.
<p>7. How to set Alarm 2?</p>	<ul style="list-style-type: none"> • Switched on the radio. • Quickly press and release ‘Alarm’ button. (‘ALARM

	<p>1' will display on the screen.). Quickly press and release 'TUNING ▲' button to show ALARM 2.</p> <ul style="list-style-type: none"> • Quickly press and release 'Select, button. Display may show 'ON' or 'OFF'. If display shows 'OFF' then quickly press and release 'TUNING ▲' button. • When display shows 'ON', quickly press and release 'Select, button. • Now select the hour for alarm time by repeatedly pressing 'TUNING ▲'. When correct hour is displayed press select button quickly. • Now select the minute for alarm time by repeatedly pressing 'TUNING ▲'. When correct minute is displayed press the 'SELECT' button quickly. • Now select the desired day option by repeatedly pressing 'TUNING ▲' then quickly press the 'SELECT' button. • Choose the desired option 'BUZZ' or 'RADIO' using 'TUNING ▲' then quickly press the 'SELECT' button. Display will show 'SAVED' – this ends the procedure for setting alarm2.
8. How to switch off Alarm.	<ul style="list-style-type: none"> • Switched on the radio. • Quickly press and release 'Alarm' button. ('ALARM 1' will display on the screen.) • Quickly press and release 'Select, button. Display may show 'ON' or 'OFF'. If display shows 'ON' then quickly press and release 'TUNING ▲' button. • When display shows 'OFF', quickly press and release 'Select, button. • The symbol for alarm 1 on the top left corner of the screen will disappear . • Follow the above procedure for alarm 2 – just select alarm 2 after the second step by quickly pressing and releasing 'TUNING ▲' button.

Unable to preset stations

Presetting stations--

1. Switch on the radio and play the desired station to be stored.
2. Press and release the 'Preset' button. (do not **hold** preset button—see note 1)
3. Press and release 'TUNING' up button to select the desired preset number. (Do not **hold** the tuning button –see note 2)
4. Now press and **hold** the 'Preset' button until the display shows 'stored'.
5. This completes the storing procedure.

Note: --

- If preset 1 is already stored then pressing and releasing 'Preset' button in step 2 will display the radio station name that was stored under preset 1.
- Similarly, in step 3 by pressing & releasing 'Tuning' button - the display will show all stations already stored and empty presets with a number.

Recalling a Preset station:--

- Switch on the radio then press and release Preset button. (Do not **hold** the button).
- Display will show the name of radio station (if shows empty then no station is stored under preset 1).
- Press and release (repeatedly) Tuning up button to select the desired station. (Do not **hold** the button).
- Press and release the select button to play the desired station. (Do not **hold** the button).
- This completes the recalling procedure.

See page 15 and 16 for full details. Remember not to hold button when it says press and release.