## SolarDAB 2 Trouble shooting Guide

<u>Important Note</u>: For any unusual problem 'System reset' your radio (see page 22) of Instruction book). An electronic copy of the latest Troubleshooting Guide can be obtained by requesting at **a.g@robertsts.co.uk** email address.

Please note: If you live in a flat, or your building is steel-framed or reinforced concrete, or if the topography of where you live means you get poor FM or mobile phone service, your DAB coverage may be affected.

|   | Remedies   |
|---|--|
| . Radio cuts out.   | <ul> <li>Make sure the aerial is installed on the top left hand side<br/>and fully extended by pulling the top section of the<br/>aerial – see page 8 step 1. Reposition the radio/aerial to<br/>get maximum signal strength (see page 10 step g).</li> <li>Make sure batteries are not flat (if using on batteries). Try<br/>radio on mains (using mains adaptor).</li> <li>Check the digital radio (DAB) coverage in your area using<br/>the link –<br/>www.ukdigitalradio.com/coverage/search/default.asp<br/>and your postcode.</li> <li>The type of building and surroundings can seriously affect the<br/>DAB reception. Sizeable concrete and metal work in the<br/>building (e.g. Block of flats, shopping centre, near or under a<br/>bridge, thermal insulation with aluminium foil) can<br/>considerably reduce the signal strength.</li> </ul> |
| 2. Display starts to fade, sound                                  | These are typical low battery symptoms (if using on  |
| oreaking up, signal strength shows<br>ow. Radio switches off.     | batteries).Charge your batteries using mains adaptor   |
| 8. Presetting station into the                                    | See page 18 for storing.   |
| nemory.   |  |
| Recalling a preset station does not work.                         | • See page 18 for recalling presets.   |
| 5. Can not receive BBC Sports                                     | • This radio station is not transmitting all the time.   |
| Extra, display shows "Not   | Transmitting details can be found using following links.<br><u>http://www.bbc.co.uk/fivelive/sportsextra/schedule.shtml</u>  |
| Available".   | http://www.bbc.co.uk/fivelive/listings/day.shtml?day=today   |
| 5. Batteries are not lasting long.                                | <ul> <li>Recharge the batteries as stated on page 4.</li> <li>New rechargeable batteries take few (charge and discharge) cycles before restoring to full capacity.</li> <li>If this does not work replace the batteries.</li> </ul>  |
| 7. Radio plays only one station.<br>Jnable to change the station. | <ul> <li>See page 9. In step 3 push the tuning control in momentarily.</li> <li>Or it may be showing only preset stations – heart symbol (♥) will show if preset selected. To cancel preset – simply press and release preset button quickly to make heart symbol disappear.</li> </ul>  |
|   |  |
| 3. Buttons do not work, radio                                     | • Disconnect the battery momentarily and try again.  |

| 9. New unit (or battery) - will not charge.        | • New or deeply discharged battery takes longer to charge.   |
|--|--|
| 10. Not generating enough charge from solar panel. | <ul> <li>Solar panel will generate maximum charge current when placed perpendicular to uninterrupted (direct) sunlight at mid day in summer. Variations, such as</li> <li>time of the day,</li> <li>month of the year,</li> <li>sky condition (cloudy etc.),</li> <li>medium between panel &amp; sunlight (e.g. glass, curtain)</li> <li>angle of the solar panel to direct sunlight can considerably reduce the amount of charge produced by the solar panel.</li> <li>Charge the battery with eco-friendly power adaptor.</li> </ul> |
| 11. Rechargeable batteries do not                  | Rechargeable batteries must be charged before use.   |
| last long after full charge.                       | • Make sure the batteries used are NiMH and <b>not</b> NiCad.  |
|  | • When new, rechargeable batteries need few charge and   |
|  | discharge cycles before restoring to full capacity.  |
|  | • To condition new batteries, disconnect the power lead when   |
|  | red light go out and reconnect the power after 10 minutes.   |
|  | Repeat this procedure 4-5 times.   |
|  | • Play time period depends on the capacity of the batteries.   |
|  | Typical 1300mAh battery should last for 6 hours when fully   |
|  | charged. Higher capacity batteries will last longer.   |
|  | • Batteries used under proper conditions can last 500 cycles   |
|  | or more see manufacturer data sheet.   |